



**Wiring Example: Zone 1
Smile 20/20P Detectors**

- EOL line values with onboard jumpers
- This example: 2K2 EOL, 1K Tamper
- Wires needed 3 - 12VDC, GND, ALARM

**Wiring Example: Zone 2
Smile 19/19P Detectors**

- EOL resistor wired in between ALARM and COM
- Tamper resistor wired inline from AP back to panel
- This example: 2K2 EOL, 1K Tamper
- Wires needed 4 - 12VDC, GND, ALARM, AP