


Installation guide

Fail-safe mode / NC relay

SALTO
inspired**access**



315mA Fast-Acting Cartridge Fuse

In-Line Fuse Holder For 5x20mm Fuses

This fuse kit must be used whenever the CU is going to be installed following one of the following cases:

- "Failsafe relay mode is used" (please refer to the SPACE manual to use this function)
- or
- The relays are used under normally closed (NC) AND the same power supply is used for the CU and for the locking device (not recommended by SALTO).

