

A HUB SETTING

- Ensure locking bar is in the unlocked (up) position. Hubs cannot be set while lock is locked.
- Using a 4mm flat blade screwdriver, rotate the dial until the required configuration is achieved. Dial can be rotated in either direction.
- **RED** - handle is lockable. Only opened by handle when locking bar is unlocked (up).
- **GREEN** - opened by handle at all times.

B CYLINDER CAM SELECTION

	X7 cam Retracts the latch bolt. Locks the locking bar.
	V cam Locks and unlocks the locking bar. Retracts the latch bolt after unlocking lock.

C ADAPTOR SELECTION

	Locking adaptor Locks and unlocks the locking bar. Does not retract the latch bolt.
	Latching adaptor Retracts the latch bolt. Does not operate the locking bar.

D ANTI-LOCKOUT OR HOLDBACK SELECTION

- The anti-lockout and hold back selection is located under the latch bolt.
- Pull latch bolt forward and rotate 90°.
- Using a 4mm flat blade screwdriver, rotate to the required function.
- **NOTE** : Selector can only be rotated 90° in either direction from the (N) neutral position.
- Rotate the latch bolt back to vertical ensuring the correct latch bolt handing.

	NEUTRAL LOCK Factory default. Lock operates as a standard lock.		HOLDBACK LOCK <i>Hold back must not be activated on fire doors.</i> Latch bolt can be held within the lock. To activate : Depress latch bolt and lock locking bar. To de-activate : Unlock locking bar
	ANTI-LOCKOUT LOCK Closing the door or retracting the latch bolt unlocks the lock preventing lock out situations.		

Nightlatches

Function description	External cam or adaptor	Hub setting	Lock function setting	Locking bar position	Internal cam or adaptor
3770-T Nightlatch with turn <i>Turn knob inside.</i> Inside : Opened by turn knob.		Red	Red	Neutral	Locked
3770X- Nightlatch with cylinder <i>Single cylinder.</i> Outside : Opened by key.	X7	Red	Red	Neutral	Locked
3770XT Nightlatch with cylinder & turn <i>Cylinder and turn knob.</i> Outside : Opened by key. Inside : Opened by turn knob.	X7	Red	Red	Neutral	Locked
3770XX Nightlatch with double cylinder <i>Double cylinder.</i> Outside : Opened by key. Inside : Opened by key.	X7	Red	Red	Neutral	Locked

Escape locks

Function description	External cam or adaptor	Hub setting	Lock function setting	Locking bar position	Internal cam or adaptor
3772-- Escape lock <i>Outside : Handle always rigid.</i> Inside : Opened by handle at all times.		Red	Green	Neutral	Locked
3772-T Escape privacy lock <i>Emergency button and turn knob.</i> Outside : Opened by handle when unlocked. Emergency button locks or unlocks outside handle - operated by screwdriver or coin. Inside : Opened by handle at all times. Turn knob locks or unlocks outside handle.		Red	Green	Neutral	Selectable
3772X- Key entry escape lock <i>Single cylinder.</i> Outside : Opened by key at all times. Handle always rigid. Inside : Opened by handle at all times.	X7	Red	Green	Neutral	Locked
3772XT Key entry escape lock & turn <i>Cylinder and turn knob.</i> Outside : Opened by key at all times. Opened by handle when unlocked. Emergency button locks or unlocks outside handle - operated by screwdriver or coin. Inside : Opened by handle at all times. Turn knob locks or unlocks outside handle.	X7	Red	Green	Neutral	Selectable
3772V- Anti-vandal escape lock <i>Single cylinder.</i> Outside : Opened by handle when unlocked. Key locks or unlocks outside handle and retracts bolt after unlocking lock. Inside : Opened by handle at all times.	V	Red	Green	Neutral	Selectable
3772VT Anti-vandal escape lock & turn <i>Cylinder and turn knob.</i> Outside : Opened by handle when unlocked. Key locks or unlocks outside handle and retracts bolt after unlocking lock. Inside : Opened by handle at all times. Turn knob locks or unlocks outside handle.	V	Red	Green	Neutral	Selectable
3772-TA Anti-lockout escape privacy lock* <i>Emergency button and turn knob.</i> Outside : Opened by handle when unlocked. Emergency button locks or unlocks outside handle - operated by screwdriver or coin. Inside : Opened by handle at all times. Turn knob locks or unlocks outside handle.		Red	Green	Anti-lockout	Selectable
3772VTA Anti-lockout anti-vandal escape lock & turn* <i>Cylinder and turn knob.</i> Outside : Opened by handle when unlocked. Key locks or unlocks outside handle and retracts bolt after unlocking lock. Inside : Opened by handle at all times. Turn knob locks or unlocks outside handle.	V	Red	Green	Anti-lockout	Selectable
3772XVH Holdback key entry lock & cylinder # <i>Double cylinder.</i> Outside : Opened by key at all times. Opened by handle when unlocked. Key locks outside handle. Key locks or unlocks outside handle and retracts bolt after unlocking lock.	X7	Red	Green	Holdback	Selectable
3772V-H Holdback anti-vandal escape lock # <i>Single cylinder.</i> Outside : Opened by handle when unlocked. Key locks or unlocks outside handle and retracts bolt after unlocking lock. Inside : Opened by handle at all times.	V	Red	Green	Holdback	Selectable

Escape locks cont.

Function description	External cam or adaptor	Hub setting	Lock function setting	Locking bar position	Internal cam or adaptor
3772VTH Holdback anti-vandal escape lock & turn # <i>Cylinder and turn knob.</i> Outside : Opened by handle when unlocked. Key locks or unlocks outside handle and retracts bolt after unlocking lock. Inside : Opened by handle at all times. Turn knob locks or unlocks outside handle.	V	Red	Green	Holdback	Selectable

Passage latch

Function description	External cam or adaptor	Hub setting	Lock function setting	Locking bar position	Internal cam or adaptor
3774 Passage latch <i>Outside : Opened by handle at all times.</i> Inside : Opened by handle at all times.		Green	Green	Neutral	Unlocked

Combination locks

Function description	External cam or adaptor	Hub setting	Lock function setting	Locking bar position	Internal cam or adaptor
3774-T Privacy lock <i>Emergency button and turn knob.</i> Outside : Opened by handle when unlocked. Emergency button locks or unlocks both handles - operated by screwdriver or coin. Inside : Opened by handle when unlocked. Turn knob locks or unlocks both handles.		Red	Red	Neutral	Selectable
3774XX Key entry double cylinder lock <i>Double cylinder.</i> Outside : Opened by key at all times. Handle always rigid. Inside : Opened by key at all times. Handle always rigid.	X7	Red	Red	Neutral	Locked
3774XV Key entry lock & internal cylinder <i>Double cylinder.</i> Outside : Opened by key at all times. Opened by handle when unlocked. Key locks both handles. Inside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock.	X7	Red	Red	Neutral	Selectable
3774VV Anti-vandal lock & internal cylinder <i>Double cylinder.</i> Outside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock. Inside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock.	V	Red	Red	Neutral	Selectable
3774VT Anti-vandal lock & turn <i>Cylinder and turn knob.</i> Outside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock. Inside : Opened by handle when unlocked. Turn knob locks or unlocks both handles.	V	Red	Red	Neutral	Selectable
3774-TA Anti-lockout privacy lock* <i>Emergency button and turn knob.</i> Outside : Opened by handle when unlocked. Emergency button locks or unlocks both handles - operated by screwdriver or coin. Inside : Opened by handle when unlocked. Turn knob locks or unlocks both handles.		Red	Red	Anti-lockout	Selectable
3774VVA Anti-lockout anti-vandal lock & cylinder* <i>Double cylinder.</i> Outside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock. Inside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock.	V	Red	Red	Anti-lockout	Selectable
3774XVH Holdback key entry lock & cylinder # <i>Double cylinder.</i> Outside : Opened by key at all times. Opened by handle when unlocked. Key locks both handles. Inside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock.	X7	Red	Red	Holdback	Selectable
3774VVH Holdback anti-vandal lock & cylinder # <i>Double cylinder.</i> Outside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock. Inside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock.	V	Red	Red	Holdback	Selectable
3774VTH Holdback anti-vandal lock & turn # <i>Cylinder and turn knob.</i> Outside : Opened by handle when unlocked. Key locks or unlocks both handles and retracts bolt after unlocking lock. Inside : Opened by handle when unlocked. Turn knob locks or unlocks both handles.	V	Red	Red	Holdback	Selectable

* **Anti-lockout lock** - closing the door or retracting the latch bolt unlocks the lock preventing lock out situations.
Hold back lock - Latch bolt can be held within the lock.
Hold back must not be activated on fire doors.