BWare[™] K-Band DT Grade 2

Model: RK515DTGL



ENGLISH

The BWare DT detector is the ultimate motion detector for professional installations, incorporating Anti-Cloak™ Technologie (ACT™) and includes built-in end-of-line (EOL) resistors to simplify installation. The detector employs K-Band microwave providing reduced wall penetration.

Installation / Maintenance

- Mounting The BWare DT can be mounted either on a flat surface or on a wall corner (corner mounting).
- Remove detector's front cover using a suitable tool (as described in Figure 1).
 Using a suitable tool, open the following knockouts on the detector's base (see Figure 2).
- To select the correct vertical adjustment position for wide angle lens, use the scale on the bottom right hand side of the PCB cover as follows: Mounting height and scale position based on room size: L-LONG S-SHORT Mounting Height

2.1m-2.7m (6'11"-8'10")	15m (50')	6m (20')

4. Set jumpers (see Jumper Setting section).

- Note: Reset the detector after each change made to the settings.
- 5. Install the front cover back to its place (in a reverse sequence of the removal

6. Perform a Walk test (see Walk Test section below).

Terminal	Wiring	(see l	Figure	5)

Terminal	Description	
- 12 +	12VDC Input	
ALARM	N.C. Relay	
TAMPER	N.C. Tamper switch	
LED	LED operation remote control	
	When an "Activation Signal"** is applied to the LED input terminal, all LEDs will be disabled. LEDs are enabled if nothing is connected (unless LED DIP is OFF) or 0V/12V is applied (according to the LED Input Jumper position, 12V or 0V).	

Activation Signal

If 12VDC is applied, and the LED Input Jumper is on 12V position (Default position)

- Or

0V is applied and LED Input Jumper is on 0V position

U.S. Patent Number: This product is protected under Patent No. US 7,126,476 B2. Other patents pending.

CE Compliance Section:

Risco Ltd. hereby declares that this equipment is in compliance with the essential requirement and other relevant provisions of Directive 1999/5/EC. For the EC Declaration of Conformity please refer to our website: www.riscogroup.com

Environmental Class II

EN 50131-1

Grade 2

EN 50131-2-4



FCC modular approval

BWare RK515DTGL FCC Compliance Section:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

Communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Recrient or relocate the receiving antenna.

FCC Warning:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

DIP Switch	Function		
SW1-1: LED	Used to determine the	operation of the detector's LEDs	
ON: (Default)	LEDs are enabled, allow terminal	EDs are enabled, allowing LED control via the LED input erminal	
OFF:	LEDs are disabled		
SW1-2: ACT	Used to determine if A	CT mode is enabled or disabled	
ON	ACT Enabled Important: Do not use ACT™ mode if you are expecting that there will be moving objects outside the required protected area, a corridor for example.		
OFF (Default)	ACT Disabled.		
guidelines. TI	n Line DT includes a Green Line feature that follows environmental is feature disables the MW channel when the alarm system is eliminating surplus MW emission while the premises is occupied.		
ON	Green Line feature is enabled: To deactivate the MW module during "UNSET", the LEDs must also be remotely disabled by the LED terminal. Note: When 'Green Line' is on (Microwave off), the detector will still activate (PIR only)		
OFF (Default)	Green Line feature in disabled: MW is constantly in use.		
SW1-4: Self Test Not applicable in this version.		version.	
J1 - Alarm E(J2 - Tamper E			
J4 - LED INPUT	Used to determine the	sed to determine the polarity of the external LED input.	
and the second s	(Default)		

RISCO Group Limited Warranty

RISCO Group and its subsidiaries and affiliates ("Seller") warrants its products to be free from defects in materials and workmanship under normal use for 24 months from the date of production. Because Seller does not install or connect the product and because the product may be used in conjunction with products not manufactured by the Seller, Seller cannot guarantee the performance of the security system which uses this product. Seller's Calified guarantee the perionnance of the security system which uses the perioduct. Seeling and obligation and liability under this warranty is expressly limited to repaining and replacing, at Seller's option, within a reasonable time after the date of delivery, any product not meeting the specifications. Seller makes no other warranty, expressed or implied, and makes no warrant yof merchantability or of fitness for any particular purpose. In no case shall seller be liable for any consequential or incidental damages for breach of this expressive understructure understructure of warranty is encounted to enclose the prior of the sector. this or any other warranty, expressed or implied, or upon any other basis of liability

whatsoever. Whatsoever. Seller's obligation under this warranty shall not include any transportation charges or costs of installation or any liability for direct, indirect, or consequential damages or delay. Seller does not represent that its product may not be compromised or circumvented; that the product will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; or that the product will in all cases provide adequate warning or protection. Seller, in one event shall be liable for any direct or indirect damages or any other losses occurred due to any type of tampering, whether intentional or unintentional such as masking, painting or spraying on the lenses, mirrors or any other part of the detector. Buyer understands that a properly installed and maintained alarm may only reduce the risk of burglary, robbery or fire without warning, but is not insurance or a guaranty that such event will not occur or that there will be no personal injury or property loss as a result thereof thereof.

Consequently seller shall have no liability for any personal injury, property damage or loss based on a claim that the product fails to give warning. However, if seller is held liable, whether directly or indirectly, for any loss or damage arising under this limited warranty or otherwise, regardless of cause or origin, seller's maximum liability shall not exceed the purchase price of the product, which shall be complete and exclusive remedy against seller.

No employee or representative of Seller is authorized to change this warranty in any way or grant any other warranty.

WARNING: This product should be tested at least once a week

CAUTION: risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to local regulations.

© RISCO Group 10/2013

5IN1749 B

CHINA (Shenzhen)

Tel: +86-755-82789285 support-cn@riscogroup.com POLAND Tel: +48-22-500-28-40 support-pl@riscogroup.com ISRAEL Tel: +972-3-963-7777 support@riscogroup.com

Walk Test

- 1. Two minutes after applying power (warm-up period), walk test the Detector over the entire protected area to verify proper operation of the
- The K-Band MW range must be adjusted using the potention of the distribution of the PCB. It is important to set the potentiometer to the lowest possible setting that will still provide enough coverage for the inner boundary protected area (see Figure 5).

LEDs Display		
LED	State	Description
Yellow	On	PIR detection
	Flashing	Trouble in PIR channel
Green	On	MW detection
	Flashing	Trouble in MW channel
Blue	On	ALARM
All LEDs	Flashing consecutively	At power-up, the LEDs will flash consecutively until the end of the warm-up period (2-3 minutes).

echnical Specification

16mA at 12VDC (typical) 41mA at 12VDC (max.)		
9 -16VDC***		
24VDC, 0.1A		
24VDC, 0.1A		
Environmental		
According to EN50130-4		
-10°C to 55°C (14°F to 131°F)		
-20°C to 60°C (-4°F to 140°F)		
Optical		
White Light Protection		
Physical		
127.6 x 64.2 x 46.6 mm (5 x 2.5 x 1.84 in.)		
120 gr. (4.2 oz.)		

*** Power to be supplied by 5A max. power source using safety approved wires, with a min Gauge of 20AWG.

Figure 1. Front cover removal



Figure 4. **EOL Resistors**



Figure 5. Figure 6. K-Band MW range adjustment

Terminal Wiring



RISCO Group Contacting Info RISCO Group is committed to customer service and product support. You can contact us through our website (www.riscogroup.com) or at the following telephone and fax numbers:

UK Tel: 44-(0)-161-655-5500

SPAIN Tel: +34-91-490-2133

FRANCE Tel: +33-164-73-28-50 support-fr@riscogroup.com

BELGIUM Tel: +32-2522-7622

support-be@riscogroup.com U.S.A Tel: +1-631-719-4400

support-usa@riscogroup.com

CHINA (Shanghai) Tel: +86-21-52-39-0066 support-cn@riscogroup.com

BRAZIL Tel: +55-11-3661-8767 support-br@riscogroup.com

support-es@riscogroup.com

support-uk@riscogroup.com ITALY Tel: +39-02-66590054 support-it@riscogroup.com

Contains FCC ID UXS-IPM165F FCC Part 15 Note: communications Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician.

- A2 Wall mounting knocko
- A3 Left corner mounting knock